

## Appliances properties: Camina & Schmid Feuerdesign und Technik GmbH & Co. KG - NEO-Line 6554 (6,9 kW)

Master data

Date of entry Oct 23, 2017

Manufacturer Camina & Schmid Feuerdesign und Technik GmbH & Co. KG

Model NEO-Line 6554 (6,9 kW)

Nominal heat output [kW] 6.9

Continuous burning appliance

Type test standard DIN EN 13229
Test laboratory TÜV Süd Kermi Kft.

Number of test laboratory 14

Number of test report R-848363-3



Flue gas values

	Wood
Flue gas mass flow [g/s]	7.1
Flue gas mass flow [g/s]	224
Necessary flue draught [Pa]	12

Further important characteristics of the appliance

Suitability for installation to a shared flue 1)

Connectivity to the central heating system

## General technical approval for room sealed operation

On behalf of the manufacturer, the HKI Industrieverband e.V. hereby confirms compliance with the respective requirements\* in accordance with 1.BImSchV. The type test report of the fireplace has been submitted to the HKI Industrieverband e.V.

<sup>1)</sup> For unsealed operation it is possible to install the appliances to a shared flue system (please see installation manual).

<sup>\*</sup>A green check mark with a "1" indicates that the requirements of the 1st BImSchV are fulfilled, a green check mark with a "2" indicates that the 2nd level of the 1st BImSchV is fulfilled. A yellow check mark shows that the transitional regulation of the 1st BImSchV is fulfilled and a red line means that the 1st BImSchV is not fulfilled.

## Evaluation of emission data and efficiency Wood

Norm : Inset appliances (with closed firedoor)	Evaluation
D - 1.BlmSchV	Stufe 2
A - Austrian regulation referred to Art 15a B-VG	2015
CH - Swiss clean air act	✓
DK - Danish regulation for air pollution from wood burners	<b>✓</b>

## Evaluation of emission data and efficiency Lignite briquettes Norm: Inset appliances (with closed firedoor) D - 1.BImSchV Evaluation

According to the transitional rule §26 the appliance can be used until 31.12.2014

DK - Danish regulation for air pollution from wood burners



No symbol means that there are no requirements.

No measuring values are available for this fuel, operation with this fuel is not permitted

Here you will find further information

No information/unknown