

Appliances properties: Max Blank GmbH - Ökofire KE-1 gerade

Master data

Date of entryMay 21, 2010ManufacturerMax Blank GmbHModelÖkofire KE-1 gerade

Nominal heat output [kW] 7

Declared nominal space heating output [kW] 7

Continuous burning appliance

Type test standard DIN EN 13229

Year of testing 2009

Test laboratory Versuchs- und Forschungsanstalt der Hafner Österreichs

Number of test laboratory

Number of test report VFH-09-015-P



Flue gas values

	Wood	
Flue gas mass flow [g/s]	15	
Flue gas mass flow [g/s]	206	
Necessary flue draught [Pa]	11	

Further important characteristics of the appliance

Suitability for installation to a shared flue 1)



Connectivity to the central heating system



¹⁾ For unsealed operation it is possible to install the appliances to a shared flue system (please see installation manual).

On behalf of the manufacturer, the HKI Industrieverband e.V. hereby confirms compliance with the respective requirements* in accordance with 1.BImSchV. The type test report of the fireplace has been submitted to the HKI Industrieverband e.V.

*A green check mark with a "1" indicates that the requirements of the 1st BImSchV are fulfilled, a green check mark with a "2" indicates that the 2nd level of the 1st BImSchV is fulfilled. A yellow check mark shows that the transitional regulation of the 1st BImSchV is fulfilled and a red line means that the 1st BImSchV is not fulfilled.

Norm: Inset appliances (with closed firedoor) D - 1.BImSchV A - Austrian regulation referred to Art 15a B-VG

A - Austrian regulation referred to Art 15a B-VG	*
CH - Swiss clean air act	✓
DK - Danish regulation for air pollution from wood burners	-
F - Crédit d'impôt à la transition énergétique	♦

Evaluation of emission data and efficiency Lignite briquettes

Evaluation of emission data and efficiency Wood

Norm : Inset appliances (with closed firedoor)	Evaluation
D - 1.BlmSchV	!
	According to the transitional rule §26 the appliance can be used until 31.12.2024
DK - Danish regulation for air pollution from wood burners	!



No symbol means that there are no requirements.

No measuring values are available for this fuel, operation with this fuel is not permitted

Here you will find further information

No information/unknown